


Assembly Instructions

Lynx 2 Door Sliding Mirrored Wardrobe



Important before assembly:

Read these instructions carefully before assembling or using the product.

Please check the contents of the boxes before attempting to assemble this product. The instructions will have a checklist of parts and fittings.


It would be sensible to lay a rug or a carpet on the floor where you intend to assemble the product, to void scratches and damaging the product or the floor.


Assemble the product as close to its intended final location/room as possible.

Do NOT use any power tools as this may damage the frame.

Health & Safety: This product or some parts of this product will be heavy. Please use an assistant when lifting. DO NOT jump on the product or any of its parts. DO NOT use this product if any parts are missing, damaged or worn. DO NOT use this product unless all fixings are secured. Please keep small parts out of reach of children. Always use on a level, even surface.

Please keep these instructions for future reference.






Never drag or push the pieces across a hard or stone floor as this will cause damage to the joints. Use a carpet or a rug for extra care.




					Vendor: S000 Identification of Accessories Part Descripion A 5 x 60 mm Screw B3 Bushing B5 Metalic Angle Plates C1 Metal Claw E 8 x 30mm Wooden Dowel E7 Small Plastic Foot E9 Strap		
Parts List					8 x 50mm Wooden Dowel	4	
	Descripion	Box	Qty	J	Simple Minifix Screw	20	
01	Top Panel	2	1	K	Double Minifix Screw	=] 4	
02	Shelf	1	1	L	Cam Lock	28	
03	Top Plinth	1	1	M	Plastic Cap	14	
04	Left Panel	1	1	N	10 x 10mm Tack	25	
05	Right Panel	1	1	P5	3,5 x 14mm Screw	2	
06	Shelf Divider	1	1	R4	Hanging Rail	1	
07	Back Support	1	1	S	3.5 x 14mm Screw	13	
08	Front Support	1	1	Т	3.5 x 25mm Screw	6	
09	Back Rail	1	4	V4	3.5 x 20mm Screw	2	
10	Bottom Plinth	1	2	V5	Open Rail Support	1	
11	Left Door	2	1	W3A	Upper Pulley	4	
12	Right Door	2	1	W3B	Lower Pulley	4	
13	Back Panel	2	2	W3C	Door Stopper	1	
14	Base Panel	1	1	W3D	4.5 x 25mm Screw ⊕ ()∆1111111	1	
** You will need a small mallet and a screwdriver for				W3E	4 x 14mm Screw ⊕	32	
assembly. ** Some screws and wooden dowel may remain.				W4	Handle	2	
** Wall plug and screw is supplied to attach strap to the wall.				W5	Top Runner	1	
				W6	Bottom Runner	1	
				Z4	Rail Support	2	



Vendor: S000139


Step 2: Attach the back rails (9) to the back support (7) using hardware parts E, K and L with a small mallet and screwdriver (not provided).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 3: Attach the back support (7) and front support (8) to the base panel (14) using hardware parts F, L and M with a small mallet and a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.









Step 8: Position the hanging rail R4 then attach the left panel (4) using hardware parts L and M with a screwdriver (not provided)


DO NOT use any power tools as this may damage the frame and will invalidate any claim.






Step 9: Put the back panels (13) in place and fix the bottom runner W6 using hardware part W3E and a screwdriver (not provided).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.







Step 10: Secure the back panels (13) using hardware parts C1 and N with a small mallet (not provided). Attach the top plinth (3) using harware part S with screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



Step 12:To secure the item to the wall use hardware parts A, B3 and E9 using a drilling machine (not provided) and a screwdriver (not provided). Then attach hardware part S to the item with a screwdriver (not provided). **Birlea Furniture advise you use the wall straps provided to further enhance the safety of this product.**





Please dispose of all packaging safely.

General Care & Maintenance

Wipe clean with a slightly damp cloth. Avoid the use of all household cleaners and abrasives.

Periodically check all screw & fixings to ensure they are secure.

When moving your product, carefully lift into place. Never drag or push the pieces across the floor as this will cause damage to the joints and could result in failure to the product that will invalidate the warranty.

For more information on cleaning and product care visit: https://www.happybeds.co.uk/help-and-advice

Notes

We've tried to make this product as easy to assemble as possible. In the unlikely event that you have problems putting it together or have damaged or missing pieces, please contact us by visiting:

https://www.happybeds.co.uk/customer-service



happybeds

www.happybeds.co.uk