

# Hampstead 2 Drawer Bedside



## **Assembly Instructions**

## Important before assembly:

Read these instructions carefully before assembling or using the product.

Please check the contents of the boxes before attempting to assemble this product. The instructions will have a checklist of parts and fittings.

Assemble the product as close to its intended final location/room as possible.

## **Health & Safety:**

This product or some parts of this product will be heavy. Please use an assistant when lifting.

Please keep small parts out of reach of children.

Always use on a level, even surface.

DO NOT jump on the product or any of its parts.

DO NOT use this product if any parts are missing, damaged or worn.


DO NOT use this product unless all fixings are secured.

#### Further instructions are on the following pages.

Please keep these instructions for future reference.



Do NOT use any power tools as this may damage the frame.






This product or some parts of this product will be heavy. Please use an assistant when lifting.







Never drag or push the pieces across a hard or stone floor as this will cause damage to the joints. Use a carpet or a rug for extra care.





If you have problems assembling or have damaged or missing pieces, please contact our customer services (details at the back of these instructions)





Parts List				
Part	Descripion	Box	Qty	
01	Top panel	1	1	
02	Bottom panel	1	1	
03	Side panel ( Left )	1	1	
04	Side panel ( Right )	1	1	
05	Front leg ( Left )	1	1	
06	Front leg ( Right )	1	1	
07	Back leg ( Left )	1	1	
08	Back leg ( Right )	1	1	
09	Front bar ( 1 )	1	1	
10	Front bar ( 2 )	1	1	
11	Leg panel	1	1	
12	Back panel	1	1	
13	Drawer front	1	2	
14	Drawer back	1	2	
15	Drawer side ( Left )	1	2	
16	Drawer side ( Right )	1	2	
17	Drawer bottom	1	2	


Hardware List ( BOX 1 )			
Description		Qty	
Cam lock	*	28	
Minifix screw		28	
Plastic cap		28	
M8 x 30mm Wood Dowel		26	
5/8 PVC Nail Leg	Q	4	
Allen key M4		1	
M3.5 x 16mm C.B Screw	<del>()</del>	32	
M4 x 20mm C.B Screw	<del>()</del> Thurston	16	
M4 x 38mm C.B Screw	<del>()</del>	8	
Handle Screw M4 x 22mm	<b>()</b> 111111111111111111111111111111111111	2	
Handle Knob 5166028 SS	8	2	
S125 - Double Hole Fitting		6	
PVC Block		8	
10" Drawer slide (Left / Right)	<u> </u>	4	
10" Drawer slide (Left / Right)	6 · · · · · · · · · · · · · · · · · · ·	4	
	Description Cam lock Minifix screw Plastic cap M8 x 30mm Wood Dowel 5/8 PVC Nail Leg Allen key M4 M3.5 x 16mm C.B Screw M4 x 20mm C.B Screw M4 x 38mm C.B Screw Handle Screw M4 x 22mm Handle Knob 5166028 SS S125 - Double Hole Fitting PVC Block 10" Drawer slide (Left / Right)	Description  Cam lock  Minifix screw  Plastic cap  M8 x 30mm Wood Dowel  5/8 PVC Nail Leg  Allen key M4  M3.5 x 16mm C.B Screw  M4 x 20mm C.B Screw  M4 x 38mm C.B Screw  Handle Screw M4 x 22mm  Handle Knob 5166028 SS  S125 - Double Hole Fitting  PVC Block  10" Drawer slide (Left / Right)	


<sup>\*\*</sup> You will need a small mallet and a screwdriver for assembly.
\*\* Some screws and wooden dowel may remain.


**Step 1:** Prepare these parts for assembly using hardware parts A1, A2, B, F and K. DO NOT use any power tools as this may damage the frame and will invalidate any claim. (A1) X4 (B)X4 **B**)X4 01 02  $(\mathsf{B})$ x2 10 (A2) X3 06 05 00 (A2) X3 15 x2 13 X2 16 x2  $(\mathsf{B})$ xı (A1) X8 B)xe (**B**)x6 03 Step 2: Fix hardware L1 onto hardware K by using hardware E. DO NOT use any power tools as this may damage the frame and will invalidate any claim. ~amm(f) Ex8 (L/R) L1 x 4 04 03

Step 3: Attach back leg (7) to side panel (3) using hardware A1 and A2 with a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.













Step 4: Attach back leg (8) to side panel (4) using hardware A1 and A2 with a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.













Step 5: Attach side panel (3) and (4) to bottom panel (2) using hardware A1 and A2 with a screwdriver (not provided).DO NOT use any power tools as this may damage the frame and will invalidate any claim.











Step 6: Insert back panel (12) along the slot.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.





Step 7: Attach front leg (5) and (6) to front bar (10) and leg panel (11).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



Step 8: Fix hardware J into front leg (5), (6), front bar (9), (10) and leg panel (11) using hardware E with a screwdriver (not provided).DO NOT use any power tools as this may damage the frame and will invalidate any claim.









Step 9: Attach front leg (5) and (6) to side panel (3) and (4) using hardware A1 and A2 with a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.













Step 10: Attach top panel (1) to side panel (3) and (4) using hardware A1 and A2 with a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.












Step 11: Hit hardware C into bottom of front leg (5), (6), back leg (7) and (8).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.








Step 12: Assemble the drawer components using hardware A3, D, E, G, H, I and L2. In this step only show one of the drawers.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.

- 1. Fix hardware I onto panel (13) by using hardware H.
- Attach drawer side (15) and (16) to drawer back (14) using hardware (G). 2.
- 3. Slide in the drawer bottom (17).
- Attach drawer front (13) to drawer side (15) and (16) using hardware A1 and A2 4.
- with a screwdriver (not provided). 5. Attach hardware (L2) to drawer sides (15) and (16) using hardware (E). 15 x2 14 X2 16 x2 ® A3 x 8 17 X2 -annum 15 x2 E x 12 16 X2 14 X2 Gx8 **(**)0000000000 Hx2 13 x2 15 X2 T 17<sub>X2</sub> lx2 ( L/R ) (A3) 16 x2 14 X2 L2 x 4 15 X2 16 x2 14 X2

Step 13: Assemble the drawers in place along the drawer slides.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.





#### **Additional Information:**

- For complete product information, images and dimension diagrams please visit the website www.birlea.com
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to <a href="mailto:info@birlea.com">info@birlea.com</a> to be shared in our #birleahome feature on instagram.

Please dispose of all packaging safely.

#### **General Care & Maintenance**

Wipe clean with a slightly damp cloth.

Avoid the use of all household cleaners and abrasives.

Periodically check all screw & fixings to ensure they are secure.

When moving your product, carefully lift into place. Never drag or push the product across the floor as this will cause damage to the joints. If the product is used on hard flooring, such as wood or laminated floor, you must place some protection under the legs to stop the product from moving. If this is not adhered to, it could result in failure to the product that will invalidate the warranty.

For more information on cleaning and product care visit: https://www.happybeds.co.uk/help-and-advice

### **Notes**

In the unlikely event that you have problems putting this product together or have damaged or missing parts, please contact us by visiting:

https://www.happybeds.co.uk/customer-service

